


## DVStick30 configuration guide and troubleshooting

- 1: Plug in the stick in the USB-port of the PC
- 2: select the correct settings in BlueDV



- 3: After entering callsign, setting baudrate (**460800**) etc, please save the settings.
- 4: Now unplug the USB-stick, wait 10 seconds, and plug it in again (reset the hardware once to be sure)  
This is no longer needed when you use the program, just for setup purposes!
- 5: click the Serial-button in BlueDV, and the unit will connect.

